

PHONE HOLDER

MAXIMUM SUCTION STRENGTH

WP ITM. PH535051

Care & Use Instructions




Important, retain for future reference:
Read carefully



5. (Optional) If your phone or case doesn't have a built-in magnet, attach the included magnetic ring to the center of the inside of your case.
6. Set your phone on the phone holder. Adjust the angle to your desired viewing position.


NOTE: Make sure the phone holder does not obstruct the driver's view. Turn off the device when not in use or during transport to prevent triggering the suction feature by accident.



CHARGING THE PHONE HOLDER

- Connect one end of the provided USB-A to USB-C cable to the charging port on the phone holder.
- Connect the other end to a power source, such as a power bank (not included), or a wall adapter* (not included).
- The indicator light will stay on red while charging and turn green once charging is complete.

Color	Status
Solid Red	Charging
Solid Green	Charging completed



NOTES:

- To ensure optimal suction performance, make sure to recharge the phone holder periodically.
- *In order to reduce the risk of fire or electric shock, an adapter shall be chosen that is suitable for the application and is certified as a Class 2 or LPS power supply or power adapter.

WARNINGS

IMPORTANT SAFETY INSTRUCTIONS

- SAVE THESE INSTRUCTIONS** – This manual contains important safety and operating instructions.
- Before using this product, read all instructions and cautionary markings.
- Do not expose the Phone Holder to rain, moisture, or snow.
- Use of an attachment not recommended or sold by the manufacturer may result in a risk of fire, electric shock, or injury to persons.
- Do not operate with damaged Phone Holder – replace it immediately.
- Do not operate the Phone Holder if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified serviceperson.
- Do not disassemble the Phone Holder; take it to a qualified serviceperson when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
- To reduce risk of electric shock, disconnect the Phone Holder before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.


CAUTIONS

- Do not install or use product if it, in any way, impairs the safe operation of your vehicle.
- Follow manufacturer's instructions to ensure the product is properly and safely installed.
- Check your state or provincial laws before installing. Vehicle owner must comply with all applicable laws.
- Manufacturer and Seller assume no liability for installation or use, which are solely the responsibility of the purchaser.
- The Manufacturer and Seller are not responsible or liable for consequential, incidental, or indirect damages, whether to person or property, resulting from the installation or improper use of this product.

MAINTAINING THE PHONE HOLDER

If the magnetic mount becomes loose from the base unit, follow these steps:

- Press the "PUSH" button to release the phone holder from the mounting surface.
- Use the included hex wrench to tighten the side screw until it is snug.
- After tightening, check to ensure the mount is stable.



FAQs

- 1) Problem: The motor keeps running.
Solution: Press the holder firmly onto the surface. If the issue persists, clean the surface with the provided cleaning paper, then reattach the holder again.
- 2) Question: What is the charging cable used for?
Answer: The included USB-C cable charges the internal battery that powers the suction feature. Please note, this phone holder is not designed to charge your phone.
- 3) Question: How can I make the battery last longer?
Answer: Clean the surface thoroughly before mounting to ensure a strong seal and prevent the suction from overworking.
- 4) Question: Does the charging cable need to stay plugged in?
Answer: No, the built-in battery typically lasts over a month with regular use. We recommend recharging it about once every 1–2 months or when the low battery alert sounds.

WARNING: This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP) and Diisononyl Phthalate (DINP), which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.


SPECIFICATIONS

Battery Capacity: 200mAh
Input Voltage: 5V DC
Magnetic Force: 1.5Kg

PACKAGE INCLUDES



Electric Vacuum Phone Holder




USB-A to USB-C Cable



Magnetic Ring



Protective Film



Hex Wrench



Screen Cleaning Paper (Wet & Dry)

FCC COMPLIANCE STATEMENT:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Phone Holder
PH535051
Responsible Party:
TYPE S
2975 Red Hill Ave., Ste. 100, Costa Mesa, CA 92626, U.S.A.
Tel: 1.866.294.9244

INSTALLING THE PHONE HOLDER

- Select a flat surface, such as your vehicle's dashboard. Clean the surface and allow it to dry completely.
- Place the phone holder on the chosen mounting location. Use the protective film for a stronger hold if needed.
- Press and hold the power button for 2 seconds to turn the device on or off. You will hear a single beep when the device turns on and two beeps when it turns off.
- With the device on, press the phone holder down to activate the vacuum suction and secure it in place.



TOURING ITEMS
TYPE S
A Horizon Brands Company
2975 Red Hill Ave., Ste. 100, Costa Mesa, CA 92626
1.866.294.9244 | info@typesauto.com
©2025 TYPE S. All rights reserved.
www.typesauto.com

CONNECT WITH US    @TypeSAuto